

ASSEMBLY INSTRUCTIONS

8. First use 4 short locking screws to ensure lateral stability.
9. Then take a plate (⑥) and two screws. Insert the screws through the plate and then through the bottom hole of the side panel and the top hole of the T-piece. Then take another plate (⑥) and insert the screws on the back through the plate. Secure the connection with washers and nuts.
10. Repeat this step mirrored on the other side. Make sure that the square holes in the side panel are facing outwards.

